

FIELD INSTALLATION INSTRUCTIONS

TITLE:	IDF FILTER CHANGE
NAME:	FII-011
ISSUE DATE:	26 June 2013
REVISION:	1

PURPOSE:

The intention of this FII is to demonstrate the procedure to change a filter.

TOOLS REQUIRED:



From Left to Right: 5/8 Wrench, Ratchet, 5/16 Socket.

FIELD INSTALLATION INSTRUCTIONS

TITLE:	IDF FILTER CHANGE
NAME:	FII-011
ISSUE DATE:	26 June 2013
REVISION:	1

PROCEDURE:



Figure 1: Center bolt removed from filter



Figure 2: Filter and gaskets



Figure 3: Replacing filter kit into cartridge

Step 1: Remove the center bolt to allow the filter to be removed.

Step 2: Locate the replacement filter kit.

Step 3: Replace filter and gaskets.

NOTE: To drain filter, remove the cartridge and dump reservoir.